

**This will help you find a good natural anchor point:**

Without using the Anchor sight or peep, install the Anchor sight frame under your front sight frame, then move your pin(s) out 1/8 inch to compensate for the frame thickness, sight your front pins on a target, at say 10 yards, using only the anchor point you come back to naturally. Shoot until you have established a grouping and feel you have found your natural anchor point. Get your groups on the bulls-eye of the target by moving your front pin. Now, sight the Anchor sight to your eye at that new anchor point by aiming at the target and glancing at the Anchor sight. When you have the dot inside the circle on the lens and are comfortable with the alignment, start shooting using the Anchor Sight. More likely than not you will see your groupings go slightly off target because you did not get the Anchor sight perfectly aligned to your new anchor point (eye position). To do this you simply move the arrow group on the bulls-eye by using the Micro adjustments. Having done this, you will have moved your anchor point to the exact same position as before.

If you are right handed... and the group is off to the left of the bulls-eye, you turn the side (horizontal) Micro screw clockwise until the group moves on target. If you are low, turn the Vertical Micro clockwise and your arrow should go up. When the arrows group on the bulls-eye, you have gotten back to the exact anchor point (eye position) you had chosen. Once you have found a good anchor point, you can sight-in using your front pins just like you did with the peep sight.