


THE SMALL DOT AND DASHES PRINTED ON THE BACKGROUND ARE NEAR ACTUAL SCALE... IF YOU PUT THE FIRST DASH THAT IS UNDER THE DOT INTO THE CENTER OF THE RED CIRCLE YOU WOULD BE CHANGING THE ANGLE OF THE BOW AND ARROW... THIS SMALL ADJUSTMENT WOULD TYPICALLY EXTEND THE RANGE OF YOUR ARROWS ANOTHER 20 YARDS DEPENDING ON YOUR ARROW SPEED.



20 YARD SIGHT PICTURE



40 YARD SIGHT PICTURE

To range your shot, choose which ever dash or space is needed to place the arrow on target at a given range. A little practice and you will determine, according to your arrow speed, what reference you use for different ranges. The difference between a 20 and 30 yard correction as viewed in the Anchor Sight is very small. We have shooters that shot 60+ yards using their 20 yard pin...

You can also extend your range by ranging from any combination of pins. You can range from your 20- 60 yard pins or, eliminate some pins leaving a 20 and 40 pin and ranging from your 20 to 30 with the Anchor Sight then from your 40 to whatever range you feel comfortable shooting.