


Getting the vertical line of the Anchor Sight parallel with your bow string is important for you to range increment correctly.



Holding the bow out at arms length, turn the bow until the string comes over the sight.

You will see the vertical line arc toward the string.

When the top and bottom of the arc touch the string at the same time and the horizontal line is centered inside the red circle, you have an accurate parallel alignment.

You make this adjustment by rotating the sight tube which is also used to adjust the sensitivity or magnification